

PARKING BRAKE

USER INSTRUCTIONS

FOR LITE, STURDY



WARNINGS

PLEASE READ BEFORE USING THE PRODUCT

-  **WARNING!** A child's safety is your responsibility.
-  **WARNING!** Read the instructions BEFORE use.
Keep these instructions for future reference.
-  **WARNING!** Never leave a child unattended.
It may be dangerous to leave your child unattended.
-  **WARNING!** This wagon is not intended for children under 3 years.
-  **WARNING!** Maximum load of the BEACHWAGON LITE is 80 KG.
Never overload.
-  **WARNING!** Never let a person stand in the wagon.
-  **WARNING!** This wagon is not suitable for running or skating.
-  **WARNING!** Assembly of the BEACHWAGON LITE by adults only!
-  **WARNING!** This wagon should be used with caution, since skill is required
to avoid falls or collisions causing injury to the user or third parties!
-  **WARNING!** Do not attach the wagon to any other vehicle, car, bicycle, motor or animal.
Do not use on highway. Only use for walking. Maximum speed 10 KM per hour.
-  **WARNING!** Always use this wagon with care to avoid injury, falling and collision.
-  **WARNING!** Always divide the load evenly over the wagon.
Overloading on one side might cause tilting of the wagon.
-  **WARNING!** When the wagon is used in the sun, there is a hazard of sun burn.
Use sun protection for children.
-  **WARNING!** Keep flames and heat away from the wagon.
-  **WARNING!** This wagon requires regular maintenance by the user.
See the maintenance instruction in this manual.
-  **WARNING!** Ensure that all accessories are engaged/constructed according
the advised instructions in the manual of these accessories before use.
-  **WARNING!** To avoid injury ensure that your child is kept away from the wagon
when unfolding and folding this wagon.
-  **WARNING!** Keep plastic covers and bags away from children to avoid suffocation
and hazard.
-  **WARNING!** Children should be kept on a distance of moving parts while
making adjustments.

ASSEMBLY

MAKE SURE YOU HAVE ALL PARTS NEEDED FOR ASSEMBLY

-1-
brake handle



tooling needed
(not included)



-4-
cable splitter




brake pins




ASSEMBLY



1 Install brake handle



2 Install brake pins on wagon (left and right)



3 Tyrap around cable



4 Adjust parking brake for good braking. See manual IN/154.1

5 Operate brake

Release position



To braking position




Braking position






Unlock button



ADJUSTING BRAKE




- 2** Add ring (see manual 127.1 - Disassemble wheel and axle)
 Shim hinzufügen (siehe Anleitung 127.1 - Rad und Achse zerlegen)
 Shim toevoegen (zie handleiding 127.1 - Wiel en as demonteren)



No braking Keine Arretierung Geen remwerking

- EN Brake pin does not touch brake disc.
 DE Bremsbolzen nicht bis Bremsscheibe.
 NL Rempin niet tot aan remschijf



Parking brake Feststellbremse Parkeerrem

- EN Brake pin protrudes sufficiently deep into brake disc.
 DE Bremsbolzen steckt tief genug in Bremsscheibe hinein.
 NL Rempin steekt voldoende diep in remschijf

**BE SURE TO CHECK OUT OUR WIDE
RANGE OF ACCESSOIRES!**



**AND MUCH MORE AT
WWW.BEACHWAGONSTROLLERS.COM**