Parking brake - assembly Feststellbremse - Montage Parkeerrem - montage.

EN DE NL





IN/112.2




Beach Wagon LITE, Parking brake for even surface. Brake not meant for sloping surfaces.

Never leave wagon unattended. Do not operate brake during moving!





Install brake handle




2 Install brake pins on wagon (left and right)





3 Tyrap around cable

4 Adjust parking brake for good braking. See manual IN/154.1



Parking brake - adjusting brake Feststellbremse - Abstellung Bremse Parkeerrem - afstellen rem

EN DE NL



IN/154.1



Beach Wagon LITE, Parking brake for even surface. Brake not meant for sloping surfaces.

Never leave wagon unattended. Do not operate brake during moving!










2 Add ring (see manual 127.1 - Disassemble wheel and axle)
Shim hinzufügen (siehe Anleitung 127.1 - Rad und Achse zerlegen)
Shim toevoegen (zie handleiding 127.1 - Wiel en as demonteren)












- **EN** Brake pin does not touch brake disc.
- **DE** Bremsbolzen nicht bis Bremsscheibe.
- NL Rempin niet tot aan remschijf



Parking brake Festellbremse

<u>Parkeerrem</u>

- **EN** Brake pin protrudes sufficiently deep into brake disc.
- **DE** Bremsbolzen steckt tief genug in Bremsscheibe hinein.
- NL Rempin steekt voldoende diep in remschijf

WARNINGS

ΕN





WARNING! A CHILD'S SAFETY IS YOUR RESPONSIBILITY.

MARNING! Never leave a child unattended. It may be dangerous to leave your child unattented.

MARNING! Read the instructions BEFORE use. Keep these instructions for future reference.

▲ WARNING! Assembly of the Beach Wagon LITE® by adults only!

MARNING! This Beach Wagon LITE® shall be used with caution, since skill is required to avoid falls or collisions causing injury to the user or third parties!

MARNING! This Beach Wagon LITE® is not intended for children under 3 years of age and maximum up to 80 KG.

▲ WARNING! This Beach Wagon LITE® is not suitable for running or skating.

MARNING! Do not attach the Beach Wagon LITE® to any other vehicle, car, bicycle, motor or animal. Do not use on highway. Only use for walking. Maximum speed 10 KM per hour.

MARNING! Avoid serious injury from falling or sliding out of the Beach Wagon LITE®.

MARNING! Always use the Beach Wagon LITE® with care to avoid injury, falling and collision.

MARNING! Maximum load of the Beach Wagon LITE® is 80 KG. Never overload. Never load more children then the Beach Wagon LITE® is suitable for.

MARNING! Always divide the load evenly over the Beach Wagon LITE®. Overloading on one side might cause tilting of the Beach Wagon LITE®.

MARNING! When the Beach Wagon LITE® is used in the sun, there is a hazard of sun burn. Use sun protection for children.

▲ WARNING! Keep flames and heat away from the Beach Wagon LITE®.

MARNING! This Beach Wagon LITE® requires regular maintenance by the user. See the maintenance instruction in this manual.

MARNING! Ensure that all accessories are engaged / constructed according the adviced instructions in the manual of these accessories before use.

MARNING! To avoid injury ensure that your child is kept away from the Beach Wagon LITE® when unfolding and folding this Beach Wagon LITE®.

MARNING! Keep plastic covers and bags away from children to avoid suffocation and hazard.

MARNING! Children should be kept on a distance of moving parts while making adjustments.

MARNING! Children may never stand in the Beach Wagon LITE® when moving.